

Volkswagen > Jetta > 2005-2008

Body Exterior

60 - Removal and Installation

.

Panorama Sunroof Sun Shade


Removing

- Move the sun shade all the way into the open position.

Note:


- ♦ *Using a hex socket head wrench, rotate shade motor into open direction to removal position if the electrical system malfunctions. ⇒ [Operating Panorama Sunroof without Electricity](#)*

- Remove the rear glass sunroof panel ⇒ [Panorama Sunroof Rear Glass Panel](#) .



- Remove the screws - **3** - from the cap - **2** - (2 Nm).
- Unclip the cap retainer - **arrow** - - **2** - from the rear lid using a screw driver - **4** - and fold the cap - **2** - up.


Do not remove the inner seal - **1** - .




- Carefully lift the shade arch - **2** - together with the sun shade slide - **1** - .

Note:

- ♦ *Be sure not to damage the shade material - **3** - .*
- Pull the sun shade slide - **1** - to the side in the direction of the - **arrow** - out of the sun shade arch - **2** - .
- Remove the headlines ⇒ Body Interior - Repair Group 70 .



- Remove the screws - **1** - for the shade cartridge - **2** - (3.5 Nm).
- Pull the sun shade cartridge - **2** - in the direction of the - **arrow** - slightly downward so that it can get past the sun shade motor - **3** - .




- Remove the sun shade cartridge - **2** - sun shade steel band - **4** - in the direction of the - **arrow** - from the sun shade rail - **1** - .

Note:

- ♦ *Be sure not to damage the shade material - **3** - .*

Remove the sun shade to replace the sun shade arch.



- Carefully remove the sun shade arch - **1** - in the direction of the - **arrow** - from the weather strip - **3** - of the sun shade material - **2** - .
- Press the new sun shade arch - **1** - carefully on the weather strip - **3** - .


Note:

- ♦ *Be sure not to damage the shade material - **2** - .*

Installing

Note:


- ♦ *The sun shade arch must be mounted prior to installing the sun shade cartridge.*
- ♦ *Do not lubricate the sun shade slide and cables.*




- Push the sun shade cartridge - **2** - sun shade steel band - **4** - in the direction of the - **arrow** - on to the sun shade rail - **1** - .

Note:

- ♦ *Be sure not to damage the shade material - **3** - .*



- Press the sun shade cartridge strap - **3** - - **2** - under the sun shade rail - **1** - .



- Press the sun shade slide - 1 - in the direction of the - **arrow** - into sun shade arch - 3 - .

Note:

- ♦ *Make sure that the sun shade glide - 1 - latches into the cut-out in the sun shade steel band - 4 - and into the sun shade coupling plate - 2 - .*

Further installation is in reverse order of removal.

Tightening torques

Sun shade cartridge screw 3.5 Nm

Cap screw 2 Nm

Note:

- ♦ *Check for ease of movement after installing the sun shade. Using a hex wrench, manually move the sun shade drive on the motor and make sure there are not creases or folds in the sun shade material.*

- Install molded headliner ⇒ Body Interior - Repair Group 70 .
- Install the rear glass sunroof panel ⇒ [Panorama Sunroof Rear Glass Panel](#)
- After completing all the work, perform a sun shade motor adaptation ⇒ [Panorama Sunroof, Adapting](#) .

Copyright © 2008 Volkswagen of America, Inc. and Bentley Publishers. All rights reserved. Last processed: