## 2004 Volkswagen Maintenance Schedule by Miles / Kilometers



Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70		80	85	90		100	
Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	16
1.9L TDI, 2.0L TDI, and 5.0L V10 Engines Only																					
Engine Oil - Change Oil and Replace Filter	X	Х		X		X		х		X		X		X		X		Х		Х	
Water Separator - Drain	X	X		X		X		X		X		X		X		X		X		X	
Fuel Filter - Replace				X				X				X				X				X	
V-Belt / Ribbed Belt - Check								X								X					
Timing Belt - Check Condition																X					
Timing Belt - Replace																				X	
1.8T and 2.0L Engines Only																					
Engine Oil - Change and Replace Filter (1.8T only)	Х	Х	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Engine Oil - Change and Replace Filter (2.0L Only)	X	X		X		X		X		X		X		X		X		X		X	
Spark Plugs - Replace								X								Х					
V-Belt / Ribbed Belt - Check								Х								Х					
Timing Belt - Check Condition (1.8T Only)												X				Х					
Timing Belt - Replace (2.0L Only)																					Х
Timing Belt and Tensioning Roller - Replace(1.8T Only)																					Х
VR6 (2.8), VR6 (3.2), W8, and W12 Engines Only																					
Engine Oil - Change Oil and Replace Filter	X	Х		Х		Х		Х		Х		X		X		Х		Х		Х	
Haldex Clutch - Change Oil (R32)								Х								Х					
V-Belt / Ribbed Belt - Check								Х								Х					
Spark Plugs - Replace								Х								Х					
2.8L V6 and 4.2 V8 (Phaeton and Touareg) Engines	Only																				
Engine Oil - Change Oil and Replace Filter (2.8 Only)	X	Х	Х	Х	Х	Х	X	Х	X	Х	X	X	Х	Х	X	Х	Х	Х	Х	Х	Х
Engine Oil - Change Oil and Replace Filter (4.2 Only)	X	Х		Х		Х		Х		Х		X		X		Х		Х		Х	
Timing Belt - Check Condition (2.8 Only)																Х					
Timing Belt and Tensioning Roller - Replace (2.8 Only)																					Х
Timing Belt - Replace (4.2 Only)																Х					
V-Belt / Ribbed Belt - Check								Х								Х					
Spark Plugs - Replace (2.8 Only)								Х								Х					
Spark Plugs - Replace (4.2 Only)												Х									

### © 2010 Volkswagen Group of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.

Revised: May 10, 2010

# 2004 Volkswagen Maintenance Schedule by Miles / Kilometers



Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105
Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	168
All Engines																					
Air Cleaner - Replace Filter								X								X					
Windshield Washer Fluid - Check Levels		X		X		X		X		X		X		X		X		X		X	
Auto-Shift Lock - Check including p/n switch		х		X		X		X		х		X		X		х		X		X	
Brake System -Check Damage/ Leaks, Pad Thickness, and Fluid Level		х		x		x		x		x		x		x		x		x		x	
Wheels - Rotate Front to Rear		х		Х		Х		Х		х		Х		Х		х		Х		х	
Battery - Check		х		Х		Х		Х		х		Х		Х		х		Х		Х	
Engine - Check for Leaks				X				X				Х				х				Х	
Dust Pollen Filter - Replace				X				X				Х				х				Х	
Cooling System - Check Level, add if Necessary				X				X				X				х				Х	
Auto Transmission - Check ATF (All models except Toua	areg)	-						X								х					
Auto Transmission - Check ATF (Touareg and Phaeton C	Only)			X				X				X				X				X	
Auto Transmission - Check for leaks				X				X				X				X				X	
Auto Trans / Final Drive - Check for Leaks (1.8T, 2.0L, and 2.8L Only)								X				X				X					
Auto Transmission - Change ATF (Eurovan Only)								X								X					
Manual Trans - Check oil levels and leaks (All models ex	cept	Touar	reg)	X				X				X				X				X	
Tires / Spare - Check Condition				X				X				X				X				X	
Drive Shafts - Check Boots				X				X				X				X				X	
OBD - Check DTC Memory and Purge				X				X				X				х				X	
Door Check Straps - Lubricate				X				X				X				х				X	
Headlights - Check and Adjust if Necessary				X				X				X				х				X	
Exhaust system - Check for damage and leaks				X				X				X				х				X	
Sunroof Frame - Clean and Lubricate				X				X				X				X				X	
Road Test				X				X				X				X				X	
Front sun roof drains: Open sun roof, check front water c	Irains	and c	clean	if nec	essar	y		X								X					
Plenum Panel: Remove cover to check water drains and	d clea	n if ne	ecess	ary				X								X					
Power Steering - Check Fluid Level (Except Touareg and	d Pha	eton)						X								X					
Power Steering - Check Fluid Level (Touareg and Phaete	on Or	nly)		X				X				X				X				X	
Interior/Exterior Lights - Check (Touareg and Phaeton O	nly)							X								X					
Air Suspension - Check (Touareg and Phaeton Only)								X								X					
Underbody - Check (Touareg and Phaeton Only)								X								X					
Direct Shift Trans (DSG) - Change Fluid								X								X					
Rear Spolier - Lubricate (New Beetle Only)		Х		X		X		X		х		X		X		X		X		X	

## 2004 Volkswagen Maintenance Schedule by Miles / Kilometers



Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105
Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	168
Front Axle - Check Dust Seals, Ball Joints, and Tie Rods				X				X				X				Х				Х	

All Vehicles - Replace Brake Fluid every 2 years, regardless of mileage. Air Bag System - Perform visual check every 12 months, regardless of mileage.

Convertible Models - Convertible Top and Rollover Protection - Check every 2 years of 20,000 (32,000KM) miles.

Touareg Only - Dust and Pollen Filter - Replace every 2 years if driven less than 40,000 miles.

Tire Filling Bottle - Replace every 4 years and Tire Pressure Monitoring System Batteries - Replace every 6 years.

Air Cleaner - Replace every 4 years if driven less than 80,000 miles.

Spark Plugs - Replace every 4 years if driven less than 40,000 miles.

#### © 2010 Volkswagen Group of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.

Revised: May 10, 2010