

MODEL 211.061 with ENGINE 112.913
 MODEL 211.065 /265 with ENGINE 112.949
 MODEL 211.080 /280 with ENGINE 112.917
 MODEL 211.082 /282 with ENGINE 112.954
 MODEL 211.261 with ENGINE 112.913
 MODEL 211.070 /270 with ENGINE 113.967
 MODEL 211.083 /283 with ENGINE 113.969
 MODEL 211.076 /276 with ENGINE 113.990
 MODEL 211.077 /277 with ENGINE 156.983
 MODEL 211.042 /242 with ENGINE 271.941
 MODEL 211.041 /241 with ENGINE 271.956
 MODEL 211.052 with ENGINE 272.922
 MODEL 211.054 /254 with ENGINE 272.943
 MODEL 211.092 /292 with ENGINE 272.944
 MODEL 211.056 /256 with ENGINE 272.964
 MODEL 211.087 /287 with ENGINE 272.972
 MODEL 211.072 /272 with ENGINE 273.960
 MODEL 211.090 /290 with ENGINE 273.962
 MODEL 211.028 with ENGINE 628.961
 MODEL 211.029 with ENGINE 629.910
 MODEL 211.020 /022 /220 /222 /620 with ENGINE 642.920
 MODEL 211.084 /089 /284 /289 with ENGINE 642.921
 MODEL 211.004 with ENGINE 646.951
 MODEL 211.006 /206 /606 with ENGINE 646.961
 MODEL 211.007 /008 /208 /608 with ENGINE 646.82
 MODEL 211.016 /216 /616 with ENGINE 647.961
 MODEL 211.023 /026 /223 /226 with ENGINE 648.961

Passenger car

Model 211



 List of service items

Customer: _____

Order number: _____

Workshop code: _____

Service code: _____

Current kilometer reading: _____

Oil grade/viscosity: _____

Customer interview and check of
brake pad lining thickness FA/RA performed:

Yes

No

Replace brake pads FA/RA

FA Yes

No

RA Yes

No

Notes/explanations: _____

Correctness of service scope confirmed by
service foreman:

Completion date



Completion of jobs confirmed by
mechanic's signature:

Completed


Not OK

Additional operations

Service 2	every 30,000 km/2 years Vehicle front, vehicle rear		
	◇ Check condition and operation of trailer hitch		◇ AP31.11-P-3152T
Service 3	Every 60,000 km/2 years Engine compartment		
	◇ Check visible area of poly-V belt for wear		◇
		Engine 112, 113, 271, 628, 646, 647, 648	AP13.22-P-1352Z
		Engine 156, 272, 273	AP13.22-P-1352TS
		Engine 629	AP13.22-P-1352TJ
		Engine 642	AP13.22-P-1352TI
	◇ Replace compressor poly-V-belt	Engine 113.990	AP13.22-P-1381R
	◇ Replace air-cleaner insert	Engine 113.990	
	◇	Engine 156.983	AP09.10-P-0980TMG
		Engine 642	AP09.10-P-0980TI
		up to VIN end no.A953599	
Service 4	Every 60,000 km/2 years Engine compartment		
	◇ Replace combination filter	With code (580) Automatic air conditioning, as of VIN end no. A635992	AP83.00-P-8384T
Service 5	Every 60,000 km/2 years Engine compartment		
	◇ Replace dust filter	With code (581) Comfort automatic air conditioning, up to VIN end no. A635991	AP83.00-P-8381T
		X170336	
	◇ Replace combination filter	With code (581) Comfort automatic air conditioning, as of VIN end no. X170337	AP83.00-P-8384T
	Passenger compartment		
	◇ Replace activated charcoal filter	Up to VIN end no. A635991	AP83.00-P-8382F
		X170336	
		with code (580) Automatic air conditioning or with code (581) Comfort automatic air conditioning	
Service 6	Every 2 years		
	◇ Check bodywork for paintwork damage by service advisor		◇ AP98.00-P-9850BA
	Underside of vehicle		
	◇ Chassis and load-bearing body components Check for damage and corrosion by service advisor		◇ AP00.20-P-0090SX
	Engine compartment		
	◇ Replace brake fluid	On vehicles with Adaptive Brake	◇ AP42.00-P-4280T
		On vehicles with SBC	◇ AP42.00-P-4280R
		i Carry out procedure "Check Sensotronic Brake Control (SBC) hydraulic unit" beforehand, refer to Service 14 or 15	
Service 7	Every 5 years Passenger compartment		
	◇ Tilting/sliding roof: clean slide rails and slide shoes		AP77.20-P-7731A
Service 8	Every 3 years Passenger compartment		
	◇ Panoramic sliding roof - clean and lubricate guide mechanism		AP77.20-P-7732PB

Service 9	Every 80.000 km/4 years	Engine compartment		
		◇ Replace air-cleaner insert	Engine 112, 113.967/ 969, 271 Engine 272, 273 Engine 628 Engine 629 Engine 642 as of VIN end no.A953600	AP09.10-P-0980TS AP09.10-P-0980TA AP09.10-P-0980TJ AP09.10-P-0980TI
		◇ Replace fuel filter	Engine 628 Engine 629 Engine 642 Engine 646 Except code (921) Rape seed oil operation, Engine 646 With code (921) Rape seed oil operation, when operating with diesel fuel Engine 647, 648	AP47.20-P-0780TD AP47.20-P-0780TJ AP47.20-P-0780TI AP47.20-P-0780T AP15.10-P-1580P
◇ Replace spark plugs	Engine 271 Except code (924) Bivalent natural gas drive	AP15.10-P-1580P		
Service 10	Every 100.000 km/4 years	Engine compartment		
◇ Replace spark plugs	Engine 112, 113 Engine 156.983 Engine 272, 273	AP15.10-P-1580AB AP15.10-P-1580TMG AP15.10-P-1580TS		
Service 11	Every 120.000 km/4 years	Engine compartment		
◇ Replace air-cleaner insert	Engine 646, 647, 648	AP09.10-P-0980T		
Service 12	Every 250.000 km/15 years	Passenger compartment		
◇ Replace fuel filter	Engine 112, 113, 156, 271, 272, 273	AP47.20-P-0780TC		
	Engine compartment			
◇ Replace coolant	 Observe correct coolant composition. Gasoline engines (not engine 156.983) Engine 156.983 Diesel engines	AP20.00-P-2080DA AP20.00-P-2080TMG AP20.00-P-2080BA		
Service 20	Once at 60.000 km	Underside of vehicle		
◇ Transfer case - oil change	Vehicles with 4MATIC	AP28.00-P-2801P		
◇ Automatic transmission - oil and filter change	Transmission 722.6 Transmission 722.9	AP27.00-P-2702I AP27.00-P-2702W		
Service 13	At each service	Engine compartment		
	◇ Engine oil and filter change	Engine 112 Engine 113.967 /969 Engine 113.990 Engine 156.983 Engine 271 Engine 272, 273 Engine 628 Engine 629 Engine 642 Engine 646, 647, 648	AP18.00-P-0101AE AP18.00-P-0101AF AP18.00-P-0101R AP18.00-P-0101TMG AP18.00-P-0101T AP18.00-P-0101TS AP18.00-P-0101TD AP18.00-P-0101TJ AP18.00-P-0101TI AP18.00-P-0101TC	
Service 14	Service 15	Not OK		
@	@	@		

Engine compartment




- | | | | | | |
|---|---|--|---|---|------------------|
| ◇ | ▽ | Check all visible parts for leaks and damage | <p>i In the event of leakage determine and eliminate subject to a separate repair invoice.</p> | ◇ | AP00.20-P-0053BA |
| ◇ | ▽ | Brake system: Check/correct fluid level | <p>i In the event of leakage determine and eliminate subject to a separate repair invoice.</p> | ◇ | AP42.10-P-4210Z |
| | ▽ | Power steering: Check/correct fluid level | <p>i In the event of leakage determine and eliminate subject to a separate repair invoice.</p> <p>i The fluid level must be, similar to the oil temperature, always at the maximum marking.</p> | ◇ | |
| | | | Gasoline engines | | AP46.00-P-4611BB |
| | | | Diesel engines | | AP46.00-P-4611P |
| ◇ | ▽ | Windshield washer system: Check/correct fluid level | <p>i Summer/winter cleaner, subject to a separate repair invoice.</p> | | AP82.35-P-8210N |
| | ▽ | Replace spark plugs | <p>i Against a separate invoice.</p> | | |
| | | | Engine 271 | | AP15.10-P-1580P |
| | | | With code (924) Bivalent natural gas drive | | |
| | ▽ | Replace fuel filter | <p>i Against a separate invoice.</p> | | |
| | | | Engine 642 | | AP47.20-P-0780TI |
| | | | with code (U41) fuel/water separator and lubrication package | | |
| | | | Engine 646 | | AP47.20-P-0780T |
| | | | with code (921) Rape seed oil operation, when operating with vegetable oil methyl ester fuel | | |
| | | | Engine 646, 647, 648 | | AP47.20-P-0780T |
| | | | with code (U41) fuel/water separator and lubrication package | | |
| ◇ | ▽ | Lubricate engine hood latch and Check safety hook's ease of operation , check. Replace components no matter how insignificant the defect | | ◇ | AP88.40-P-8851T |

Vehicle interior




<p>∇ Conduct brake test on test stand.</p> <p>Enter brake values in kilonewton:</p> <p style="padding-left: 40px;">Front Rear Parking brake</p> <p>Left</p> <p>Right</p>	<p>i In vehicles with seat belt buckle sensors, 4MATIC, ASR, ETS, ESP, SBC observe notes in maintenance manual.</p>	<p>AP42.00-P-4290R</p> <p>◇</p>
<p>◇ ∇ Reset ASSYST PLUS service interval indicator in instrument cluster</p>	<p>Vehicles up to 09/03</p> <p>Vehicles as of 09/03</p>	<p>AP00.20-P-0042T</p> <p>AP00.20-P-0042TA</p>
Function test		
<p>◇ ∇ Horn</p>		<p>◇</p>
<p>◇ ∇ Indicator lamps in instrument cluster and interior illumination</p>		<p>◇ AP54.30-P-5452C</p>
<p>◇ ∇ Check audible warning system</p>	<p>Only on vehicles with Sensotronic Brake Control (SBC)</p>	<p>◇ AP54.30-P-5450A</p>
<p>◇ ∇ Windshield wiper Windshield washer system Headlamp cleaning system</p>		<p>◇ AP82.30-P-8252A</p>
<p>∇ Check seat belts and seat belt buckles for external damage and proper operation</p>		<p>◇ AP91.40-P-9150M</p>
<p>◇ ∇ Check Sensotronic Brake Control (SBC) hydraulic unit added</p>	<p>Only on vehicles with Sensotronic Brake Control (SBC)</p>	<p>◇ AP42.50-P-4259A</p>

Wheels, brakes




<p>∇ Check wheels for damage and crack formation, measure tread depth and enter in millimeter:</p> <p style="padding-left: 40px;">VL FR RL RR</p> <p>outside</p> <p>center</p> <p>inside</p>	<p>Reposition wheels according to findings</p>	<p>◇ AP40.10-P-4051Z</p>
<p>◇ ∇ Check brake pads for lining thickness, front and rear</p>	<p>i Only if no customer interview was carried out.</p>	<p>◇ AP42.10-P-4253A</p>
<p>◇ ∇ Check/correct tire pressure and enter in bar or psi:</p> <p style="padding-left: 40px;">Front axle Rear axle</p> <p>bar/psi</p>		<p>◇</p>

Underside of vehicle




- ◇ AP00.20-P-0053BA
◇ AP33.20-P-3353BA
◇ AP41.10-P-4152Z
◇ AP46.00-P-4653F

Vehicle front end, vehicle rear end



- ◇ AP82.10-P-8260T
◇ AP82.30-P-8253G

Trunk



- ◇ AP40.10-P-4054R
- ◇
- ◇
- ◇ AP54.10-P-5410A